Dear Customer,

Thank you very much for purchasing this Scart-to-HDMI adapter. Here's how to easily convert analog Audio and video signals into digital signals.

Please read these operating instructions and follow the listed instructions and tips to ensure you can use your new Scart-to-HDMI adapter to its full potential.

Scope of delivery

- Scart-to-HDMI adapter
- USB cable for powering the adapter, approx. 80 cm (Power supply not included)
- User manual

Additionally required:
- HDMI cable
- Scart cable


Optional accessories

- USB power supply, e.g. PX-2421, available at www.pearl.de

Technical data

Input voltage	5 V DC
Power consumption	3 W
Scart input	PAL NTSC3.58., NTSC4.43, SECAM PAL/M PAL/N
HDMI output	HDMI 1.3 1080p/ 720p (60 Hz)
Protection class	3
Operating temperature	-10 ~ +55 °C
Mass	88 x 58 x 22 mm
Weight	65 g

Product details



1. 1080p/720p switch for adjusting the HDMI resolution
2. HDMI port
3. Operating LED
4. Power supply connection
5. Scart connection

use

1. Connect the HDMI output of your adapter to the HDMI input of your TV.
2. Connect the SCART input of your adapter to the SCART output of the desired device, e.g. Your DVD player or video game console.
3. Connect your adapter to a power source using the USB cable, e.g. Your television or a power outlet (power adapter not included). The operating LED is now lit.

A NOTICE:

In rare cases, the television's power supply is insufficient. In such a case, connect your adapter to a power supply.

4. Adjust the HDMI output signal to match your screen resolution by moving the 1080p/720p switch on the HDMI output side of your adapter.

A NOTICE:

Plug and Play: Your Scart-to-HDMI adapter works without the installation of drivers. Simply connect it to your devices.

Safety instructions

- This user manual is designed to familiarize you with how this product works. Therefore, keep these instructions in a safe place so that you can refer to them at any time. Pass them on to subsequent users.
- Please observe the safety instructions when using the product.
- Modifying or altering the product will compromise product safety. Caution: Risk of injury!
- All modifications and repairs to the device or accessories may only be carried out by the manufacturer or by persons expressly authorized by the manufacturer.
- Ensure that the product is operated from an easily accessible power outlet so that you can quickly disconnect the device from the mains in an emergency.
- Never open the product yourself. Never attempt repairs yourself!
- Handle the product carefully. It can be damaged by bumps, blows, or falls from even a low height.
- Keep the product away from moisture and extreme heat.
- Never immerse the product in water or other liquids.
- Technical specifications subject to change without notice. Errors and omissions excepted.


Important disposal information

This electrical appliance does not belong in household waste. For proper disposal, please contact the public collection points in your community.
Details regarding the location of such a collection point and any possibly Please refer to the information provided by the respective municipality for any existing quantity restrictions per day/month/year.

© REV1 – November 3, 2020 – CR//RM

Declaration of Conformity

PEARL.GmbH hereby declares that the product ZX-3028 is in compliance with the RoHS Directive 2011/65/EU + (EU)2015/863 and the EMC Directive 2014/30/EU.



Quality Management, Dipl. Ing. (FH) Andreas Kurtasz

The full declaration of conformity can be found at www.pearl.de/support. Enter the item number ZX-3028 in the search field there.

Information and answers to frequently asked questions (FAQs) about many of our products, as well as necessary Updated manuals can be found on the website:

auvisio

Enter the item number or item name in the search field there.

© REV1 – November 3, 2020 – CR//RM