

Dear Customer,

Thank you very much for purchasing this plaster casting kit.

Please read these operating instructions and follow the listed instructions and tips to ensure you can use your new plaster casting kit to its full potential.

Scope of delivery

- Plaster bag
- metal can
- Stand
- User manual

Technical data

Mass	16.5 x 16.5 x 3.2 cm
Weight	510 g

use

1. Place the plaster bag in warm water (approx. 35 °C), so that the plaster softens.
2. Take the plaster out of the bag and knead it vigorously for 5-10 minutes. If the plaster is not malleable enough, add a few drops of water.
3. Place the plaster in the metal can and squeeze it out with both hands. To achieve a smooth surface, also press out the fingerprints on the back. Then wash your hands with soap and water.
4. Press your child's hand or foot into the plaster cast, applying even pressure. Depending on the thickness of the cast, you may need to press the plaster in different places for about 20 seconds, e.g. 20 seconds on the palm of the hand, then 20 seconds on the fingers.
5. Wash the child's hand or foot with soap and water to remove any plaster residue.
6. Leave the can open for 3 days to allow the plaster to harden completely. The plaster shrinks slightly during the drying process.

Safety instructions



Danger!

Not suitable for children under 36 months. Choking hazard due to swallowing! Adult supervision required. This is not a toy. Keep out of reach of small children.

- This user manual is designed to familiarize you with how this product works. Therefore, keep these instructions in a safe place so that you can refer to them at any time. Pass them on to subsequent users.
- Please observe the safety instructions when using the product.
- The product, its accessories and packaging are not toys for children. Therefore, keep children away from it. Children must be supervised to ensure they do not play with the device.
- Modifying or altering the product will compromise product safety. Caution: Risk of injury!
- Handle the product carefully. It can be damaged by bumps, blows, or falls from even a low height.
- Keep the product away from moisture and extreme heat.
- Never immerse the product in water or other liquids.
- Check the product for damage before use. Do not use it if it shows visible damage.
- Never use the product after a malfunction, e.g. if it has fallen into water, been dropped, or damaged in any other way.
- Technical specifications subject to change without notice. Errors and omissions excepted.